



WALL FIX INSTRUCTIONS. IMPORTANT: PLEASE READ BEFORE INSTALLING.


1. Hold the wider end of the bracket to the wall and mark holes to be drilled:




2. Drill Holes where marked for fixings suitable for wall material (PLEASE NOTE,: we do not supply screws or anchor bolts as we cannot specify the type of wall material the sign will be fixed to).

IMPORTANT: WE STRONGLY RECOMMEND ANCHOR BOLTS OR SCREWS WITH A HEX SHAPE HEAD, AS THESE CAN BE ACCESSED TO SECURE WITH A SPANNER FROM THE SIDE OF THE SIGN WHEN AGAINST THE WALL.

3. Using the Channel Bolts supplied, slide the bracket into the channel and tighten:



4. Fix the sign & brackets to the wall. A birds-eye-view of the arrangement is shown below:





If you require help with this product, please call us on 01706 873866.