



WALL FIX INSTRUCTIONS.

IMPORTANT: PLEASE READ BEFORE INSTALLING.

THE ICE GUARDIAN UNIT IS ALREADY SWITCHED ON FOR YOUR CONVENIENCE.

THERE IS NO NEED TO REMOVE THE BATTERY ON ANY NEWLY PURCHASED SIGN


1. Hold the wider end of the bracket to the wall and mark holes to be drilled:



2. Drill Holes where marked for fixings suitable for wall material (PLEASE NOTE,; we do not supply screws or anchor bolts as we cannot specify the type of wall material the sign will be fixed to).

IMPORTANT: WE STRONGLY RECOMMEND ANCHOR BOLTS OR SCREWS WITH A HEX SHAPE HEAD, AS THESE CAN BE ACCESSED TO SECURE WITH A SPANNER FROM THE SIDE OF THE SIGN WHEN AGAINST THE WALL.

3. Using the Channel Bolts supplied, slide the bracket into the channel and tighten :



4. Fix the sign & brackets to the wall. A birds-eye-view of the arrangement is shown below:

